



1. Lens Cap
2. Trigger
3. Battery

4. Power Button
5. Down Button
6. Up Button
7. Enter Button



Getting Started

1. Insert **Battery** and wait 10 seconds.



2. Remove **Lens Cap**.



3. Remove **Sight Cap**.



4. Press and hold **Power Button** for 2 seconds.

5. After "Self-test Successful" message, point Gas Laser at the ground in front of you.

6. Pull **Trigger** until it clicks. Green pointer will flash.

7. Take readings.

Green pointer is usefull with short distances or low light conditions.

Red-dot sight is usefull for longer distances or bright conditions.



TELEDYNE
GAS MEASUREMENT INSTRUMENTS
Everywhereyoulook™

Part Number: 106221
Issue 1
www.TeledyneGFD.com